



## 12.PCV Valve

### A: REMOVAL

1) Disconnect the PCV hose.



2) Remove the PCV valve from rocker cover.



### B: INSTALLATION

Install in the reverse order of removal.

NOTE:

Apply liquid gasket to the bolt threads of PCV valve.

**Liquid gasket:**

**THREE BOND 1141 (Part No. 004403006) or equivalent**

**Tightening torque:**

**25 N·m (2.5 kgf-m, 18 ft-lb)**

## **PCV Valve**

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

---

# INTAKE (INDUCTION)

# *IN(H6DO)*

---

	Page
1. General Description .....	2
2. Air Cleaner Element .....	4
3. Air Cleaner Case .....	5
4. Air Intake Chamber .....	6
5. Air Intake Duct .....	7
6. Resonator Chamber .....	8